Atrust All-in-One - a100W

1 MENU
Opens, selects or exits the OSD menu.

2 ▼
Navigates backward through the OSD menu and decreases adjustment levels.

3 ▲
Navigates forward through the OSD menu and increases adjustment levels.

4
OSD menu selection enter key.

5 Auto
Press [Auto] button to adjust the screen brightness.

6 ⏻
* Press ⏻ to ***turn on*** the system.
* Press ⏻ for more than 4 sec. forces the client to ***shut down***.
* Press ⏻ to ***connect to*** the server.
* Press ⏻ to ***disconnect from*** the session while connected to a virtual desktop.

7 Power LED
Indicates the status of power.

8 LAN Port
Connects to a host server through a LAN switch.

9 USB Port
Connect to USB device.

10 USB Port
Connect to USB device.

11 Kensington Lock Slot
Attach the **a100W** to a permanent object with the Kensington slot and a security cable.

12 Microphone Port
Connects to a microphone.

13 Headphone Port
Connects to a headphone or a speaker system.

14 USB Port
Connect to USB devices.

15 DC IN
Connects to an AC adaptor.

Atrust All-in-One - a100W

System	
Processor	Teradici TERA2321
Memory	
System memory	512MB
Display	
LCD Type/Resolution	21.5″ LED Backlight / 1920x1080 pixel
I/O Interfaces	
I/O ports	4 x USB, 1 x RJ-45, 1 x Headphone port, 1 x Microphone port, 1 x DC IN
Networking	
Ethernet	10/100/1000Mb
Dimensions / Weight	
Dimensions	(W) 495.6 x (D) 11.5 x (H) 292.2 mm
Weight	3.2kg (approximate)
Environment	
Cooling	Fanless
Operating noise	No noise
Operating temperature	0˚C ~ 35˚C
Non-operating temperature	-30˚C ~ 60˚C
Operating humidity (Rh)	10% ~ 90% (non-condensing)
Non-operating humidity (Rh)	5% ~ 95%
AC Adaptor	
Operating voltage range	100 ~ 240 VAC
Rated line frequency	50 ~ 60 Hz
AC Adaptor	19V, 65W, 3.42A
Software	
Protocols	VMware View
Regulatory	CB, FCC, CE, NRTL

© 2013 Atrust Computer Corp. The information contained herein is subject to change without notice. Atrust shall not be liable for technical or editorial errors or omissions contained herein. Microsoft and Windows are trademarks of the Microsoft group of companies. To learn more, visit www.Atrustcorp.com.

Revision A

Atrust Computer Corp.
3F, 361 Fusing 1st Rd., Gueishan, Taoyuan County 333, Taiwan
T.+886-3-3288837 F.+886-3-3288973
sales@atrustcorp.com www.atrustcorp.com

R35471